

INSTRUCTION SHEET

安裝說明 安装说明

- ▲ Analog Output Module
- ▲ 類比輸出模組
- ▲ 模拟输出模块



Warning


- Please read this instruction carefully before use.
- Switch off the power before wiring.
- DVP04DA-H2 is an OPEN-TYPE device and therefore should be installed in an enclosure free of airborne dust, humidity, electric shock and vibration. The enclosure should prevent non-maintenance staff from operating the device (e.g. key or specific tools are required to open the enclosure) in case danger and damage on the device may
- ✓ DO NOT connect input AC power supply to any of the I/O terminals; otherwise serious damage may occur. Check all the wiring again before switching on the power.
- ✓ DO NOT touch any terminal when the power is switched on. DO NOT touch any internal circuit in 1 minute after the power is switched off.
- ✓ Make sure the groud terminal ⊕ is correctly grounded in order to prevent electromagnetic interference.

• Introduction

■ Model Explanation & Peripherals


- Thank you for choosing Delta DVP series PLC. The data in DVP04DA-H2 can be read or written FROM/TO instructions given by the program of DVP-EH2 series MPU. The analog signal output module receives 4 groups of 12-bit digital data from PLC MPU and converts the data into 4 points of analog signals for output in either voltage or current.
- You can select voltage or current output by wiring. Range of voltage output: 0V ~ +10V DC (resolution: 2.5mV). Range of current output: 0mA ~ 20mA (resolution: 5µA).

■ Product Profile (Indicators, Terminal Block, I/O Terminals)



① DIN rail (35mm)	Terminals
Connection port for extension modules	7 Mounting hole
Model name	I/O terminals
POWER, ERROR, D/A indicator	Mounting port for extension modules
DIN rail clip	

■ External Wiring



- When performing analog output, please isolate other power wirings
- 2. If the rinnles at the loaded input terminal are too significant that causes noise interference on the wiring connect the viring to 0.1 - 0.47μF 25V capacitor.
- 3. Please connect the

 terminal on both the power modules and DVP04DA-H2 to the system earth point and ground the system contact or connect it to the cover of power distribution cabinet

9 Specifications

Digital/Analog (4D/A) module	Voltage output	Current output
Power supply voltage	24V DC (20.4V DC ~ 28.8V DC) (-15% ~ +20	1%)
Analog output channel	4 channels/module	
Range of analog output	0 ~ 10V	0 ~ 20mA
Range of digital data	0 ~ 4,000	0 ~ 4,000
Resolution	12 bits (1 _{LSB} = 2.5mV)	12 bits (1 _{LSB} = 5μA)
Output impedance	0.5Ω or lower	
Overall accuracy	±0.5% when in full scale (25°C, 77°F) ±1% when in full scale within the range of 0 ~	55°C, 32 ~ 131°F
Responding time	3ms × the number of channels	
Max. output current	10mA (1KΩ ~ 2MΩ)	-
Tolerable load impedance	-	0 ~ 500Ω
Digital data format	11 significant bits out of 16 bits are available;	in 2's complement.
Isolation	Internal circuit and analog output terminals ar	e isolated by optical coupler.
ISUIALIUTI	No isolation among analog channels.	
Protection	Voltage output is protected by short circuit. SI damage on internal circuits. Current output ca	
Communication mode	ASCII/RTU mode.	
(RS-485)	Communication speed: 4,800/9,600/19,200/3	., ,
	ASCII data format: 7-bit, even bit, 1 stop bit (
	RTU data format: 8-bit, even bit, 1 stop bit (8,	
	RS-485 cannot be used when connected to F	
When connected to DVP-PLC MPU in series	The modules are numbered from 0 to 7 autor the closest to MPU and No.7 is the furthest. In MPU and will not occupy any digital I/O points	Maximum 8 modules are allowed to connect to

Other Specifications

Power supply								
Max. rated power consumption	24V DC (20.4V DC ~ 28.8V DC) (-15% ~ +20%), 4.5W, supplied by external power.							
Environment								
Operation/storage	Operation: 0 °C ~ 55 °C (temperature); 50 ~ 95% (humidity); pollution degree 2							
Operation/storage	Storage: -25 °C ~ 70 °C (temperature); 5 ~ 95% (humidity)							
Vibration/shock immunity	International standards: IEC 61131-2, IEC 68-2-6 (TEST Fc)/IEC 61131-2 & IEC 68-2-27 (TEST Ea)							

© Control Registers

CR #	RS-485 parameter address	Lat	ched	Register content	b15	b14	b13	b12	b11	b10	b9	b8	b7 t	6 b5	b4	b3	b2 b	1 b0
#0	H'4032		R	Model name	The	use	r can	read	d the	DVP mod	lel na							i1. I see
#1	H'4033		R/W	Output mode setting	Out Mod Mod Mod	put i de 0: de 1: de 2:	Volta Volta Curi	: De age (age (fault outpu outpu outpu	CH4 = H'(it (0\ it (2\ it (4n it (0n	0000 / ~ 1 / ~ 1 nA ~	0V) 0V) 20n	,		CH2	!	CI	H1

be set up separately. For example, if the user needs to set up CH1: mode 0 (b2 ~ b0 = 000); CH2: mode 1 (b5 ~ b3 = 001), CH3: mode 2 (b8 ~ b6 = 010) and CH4: mode 3 (b11 ~ b9 = 011). CR#1 has to be set as H'000A and the higher bits (b12 -

## H4038 X RW CH1 output value Range of output value at CH1 ~ CH4: K0 ~ K4,000 ## H4038 X RW CH3 output value Default = K0 (unit: LSB) ## H4038 X RW CH4 output value Default = K0 (unit: LSB) ## H4048 RW Adjusted CFFSET value of CH1 ## H4046 RW Adjusted OFFSET value of CH2 ## H4046 RW Adjusted OFFSET value of CH3 ## H4046 RW Adjusted OFFSET value of CH3 ## H4046 RW Adjusted GAN value of CH4 ## H4048 RW Adjusted GAN value of CH1 ## H4048 RW Adjusted GAN value of CH2 ## H4049 RW Adjusted GAN value of CH3 ## H4049 RW Adjus	D15)	nave to be	e re	serve	Default value = H 0000.	
#8	#6	H'4038	×	R/W	CH1 output value	
## H4038	#7	H'4039	×	R/W	CH2 output value	Range of output value at CH1 ~ CH4: K0 ~ K4,000
#15 H-4044	#8	H'403A	×	R/W	CH3 output value	Default = K0 (unit: LSB)
##9 H-4045	#9	H'403B	×	R/W	CH4 output value	
## H4045 RW Agusted OFFSET value of CH2 20 H4046 RW Agusted OFFSET value of CH2 21 H4047 RW Agusted OFFSET value of CH4 22 H4047 RW Agusted GAN value of CH4 25 H4048 RW Agusted GAN value of CH4 25 H4048 RW Agusted GAN value of CH4 26 H4048 RW Agusted GAN value of CH4 27 H4048 RW Agusted GAN value of CH4 28 H4048 RW Agusted GAN value of CH4 28 H4048 RW Agusted GAN value of CH4 29 H4048 RW Agusted GAN value of CH4 20 H4048 RW Agusted GAN value of CH4 21 H4048 RW Agusted GAN value of CH4 22 H4048 RW Agusted GAN value of CH4 22 H4048 RW Agusted GAN value of CH4 23 H4048 RW Agusted GAN value of CH4 24 H4048 RW Agusted GAN value of CH4 25 H4048 RW Agusted GAN value of CH4 26 H4048 RW Agusted GAN value of CH4 26 H4048 RW Agusted GAN value of CH4 27 H4048 RW Agusted GAN value of CH4 28 H4048 RW Agusted GAN value of CH4 28 H4048 RW Agusted GAN value of CH4 29 H4048 RW Agusted GAN value of CH4 20 H4048 RW Agusted GAN value of CH4 21 H4048 RW Agusted GAN value of CH4 22 H4048 RW Agusted GAN value of CH4 23 H4048 RW Agusted GAN value of CH4 24 H4048 RW Agusted GAN value of CH4 25 H4048 RW Agusted GAN value of CH4 26 H4048 RW Agusted GAN value of CH4 27 H4048 RW Agusted GAN value of CH4 28 H4048	#18	H'4044		R/W	Adjusted OFFSET value of CH1	D (OFFOFT 10114 0114 1/ 0 000 1/0 000
#20 H4046 RW Adjusted OFFSET value of CH3 #21 H4047 RW Adjusted OFFSET value of CH4 #24 H404A RW Adjusted GAN value of CH1 #25 H404B RW Adjusted GAN value of CH2 Default = K2.000 (unit: LSB)	#19	H'4045		R/W	Adjusted OFFSET value of CH2	
#224 H'404A O RW Adjusted GAIN value of CH1 #225 H'404B O RW Adjusted GAIN value of CH2 Range of GAIN at CH1 ~ CH4: K0 ~ K4,000 Default = K2.000 (unit: LSB)	#20	H'4046		R/W	Adjusted OFFSET value of CH3	Delault = KU (utilt: LSB)
#25 H'404B R/W Adjusted GAIN value of CH2 Range of GAIN at CH1 ~ CH4: K0 ~ K4,000 Default = K2,000 (unit: LSB)	#21	H'4047		R/W	Adjusted OFFSET value of CH4	
#25 H'404B O R/W Adjusted GAIN value of CH2 Default = K2.000 (unit: LSB)	#24	H'404A		R/W	Adjusted GAIN value of CH1	D (048) 1014 014 1/0 1/4 000
#26 H'404C R/W Adjusted GAIN value of CH3	#25	H'404B		R/W	Adjusted GAIN value of CH2	
	#26	H'404C		R/W	Adjusted GAIN value of CH3	Delault = K2,000 (unit. ESB)

CR #	RS-485 parameter address	Latched	Register content	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b
---------	--------------------------------	---------	------------------	-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	---

#27 H'404D O R/W Adjusted GAIN value of CH4

CR#18 ~ CR#27: Please note that: GAIN value - OFFSET value = +400_{LS8} ~ +6,000_{LS8} (voltage or current). When GAIN OFFSET is small (steep oblique), the resolution of output signal will be finer and variation on the digital value will be greater. When GAIN - OFFSET is big (gradual oblique), the resolution of output signal will be rougher and variation on the digital value will be smaller.

# 30	H'4050	×	R	Error statu	S		See th						format	ion.	
R#	30: Error s	tatu	s valu	e (See the t	able below)										
	E	rror	statu	3	Content	b15	~ b8	b7	b6	b5	b4	b3	b2	b1	b0
Α	bnormal po	wer	supp	oly	K1 (H'1)			0	0	0	0	0	0	0	1
In	correct an	alog	input	value	K2 (H'2)			0	0	0	0	0	0	1	0
In	Incorrect mode setting		K4 (H'4)			0	0	0	0	0	1	0	0		
0	FFSET/GA	AIN e	error		K8 (H'8)	Reserved		0	0	0	0	1	0	0	0
Н	ardware m	alfu	nction	1	K16 (H'10)	Hes	ervea	0	0	0	1	0	0	0	0
Α	bnormal di	gital	rang	е	K32 (H'20)			0	0	1	0	0	0	0	0
In	correct ave	erag	e tim	es setting	K64 (H'40)			0	1	0	0	0	0	0	0
In	struction e	rror			K128 (H'80)			1	0	0	0	0	0	0	0

Note: Each error status is determined by the corresponding bit (b0 - b7) and there may be more than 2 errors occurring at the same time. 0 = normal; 1 = error.

Example: lif the digital input exceeds 4,000, error (K2) will occur. If the analog output exceeds 10V, both analog input value error K2 and K32 will occur.

#31	H'4051	R/W	Communication address setting	For setting up RS		ication add	dress.	
				Range: 01 ~ 254.	Default = K1			
				Default = H'0002. /9,600/19,200/38,				ed: 4,80
				ASCII data forma	: 7-bit, even b	it, 1 stop b	it (7, E, 1)	
				RTU data format:	8-bit, even bit	, 1 stop bit	(8, E, 1).	
				b0: 4,800 bps. b1	9,600 bps (D	efault).		
			Communication speed (baud	b2: 19,200 bps. b	3: 38,400 bps			
#32	H'4052	R/W	rate) setting	b4: 57.600 bps. b	5: 115,200 bp:	i.		
			· -	b6 ~ b13: Reserv	ed.			
				b14: High/low bit RTU mode).	exchange of C	RC check	sum (only	valid in
				b15: Switch between (Default).	en ASCII/RTI	J mode. 0	= ASCII m	ode
								CH1
				Reserved	CH4	CH3	CH2	CH1
				Reserved Default = H'0000.				4
#33	H'4053	R/W	Return to default setting; OFFSET/GAIN tuning		Take the setti he user is allo CR#24 (GAIN wed to tune C	ng of CH1 wed to tun l) of CH1.	for examp e CR#18 When b0	le:
#33	H'4053	R/W		Default = H'0000. 1. When b0 = 0, t (OFFSET) and user is not allo	Take the setti he user is allo CR#24 (GAIN wed to tune C	ng of CH1 wed to tun l) of CH1. R#18 (OFI	for examp e CR#18 When b0 = FSET) and	le: 1, the CR#24

CR#33: For authorizations on some internal functions, e.g. OFFSET/GAIN tuning. The latched function will store the

outp	output setting in the internal memory before the power is cut off.								
#34	H'4054	0	R	Firmware version	Displaying the current firmware version In hex; e.g. version 1.0A is indicated as H'010A.				
#35	#35 ~ #48 For system use.								
_									

1 atched (when written in through RS-485 communication):

: Non-latched:

R: Able to read data by FROM instruction or RS-485 communication

W: Able to write data by TO instruction or RS-485 communication.

LSB (Least Significant Bit):

For voltage output: 1LSB = 10V/4,000 = 2.5mV. For current output: 1LSB = 20mA/4,000 = 5µA.

CR#0 ~ CR#34: The corresponding parameter addresses H'4032 ~ H'4054 are for users to read/write data by RS-485 communication. When using RS-485, the user has to separate the module with MPU first.

- a. Communication baud rate: 4,800/9,600/19,200/38,400/57,600/115,200 bps.
- b. Modbus ASCII/RTU communication protocols: ASCII data format (7-bit, even bit, 1 stop bit (7, E, 1)); RTU data format (8-bit, even bit, 1 stop bit (8, E, 1)).
- c. Function: H'03 (read register data); H'06 (write 1 word datum to register); H'10 (write many word data to
- d. Latched CR should be written by RS-485 communication to stay latched. CR will not be latched if written by MPU through TO/DTO instruction

9 Adjusting D/A Conversion Curve

Voltage output mode



Current output mode




- ✓ 請在使用之前·詳細閱讀本使用說明書。
- ✓ 實施配線·務必關閉電源。
- ✓ 本機為開放型 (OPENTYPE) 機殼・因此使用者使用本機時,必須將之安裝於具防壓、防剂及免於電擊/衝擊 意外之外殼配線箱內。另必須具備保護措施〔如:特殊之工具或鑰匙才可打開〕防止非維護人員操作或意外 衝擊本體·治成在阶及指增
- ✓ 輸入電源不可連接於輸入/出信號端、否則可能造成嚴重的損壞、因此請在上電之前再次確認電源配線。
- ✓ 請勿在上電時期提任何端子。輸入電源切斷後,一分鐘之內,請勿關提內部電路
- ✓ 本體上之接地端子●務必正確的接地,可提高產品抗雜訊能力

● 產品簡介


- 說明及週邊裝置
- 咸遊你採用台灣 DVP 系列紊息、DVP04DA-H2 類比信餘輸出權組可透過 DVP-EH2 系列主機投去以指令 FROM/TO 來讀 寫 DVP04DA-H2 類 比信階輸出模組 之資料 · 而類 比信階輸出模組接 受來自 PLC 主機的 4 組 12 位元數位資料·再將數位資料轉換爲 4 點類比信號輸出(電壓或電流皆可)
- 使用者可經由配線深擇電壓輸出或電流輸出、電壓輸出範圍 0V~+10V DC (解析度為 2.5mV)。電流輸出 節間 0mA~20mA(解析度為5uA)。

■ 產品外觀及各部介紹



0	DIN 軌槽 (35mm)	6	端子
0	擴充機/擴充模組連接口	Ø	固定孔
3	機種名稱	(8)	端子配置
•	電源、錯誤及轉換指示燈	9	擴充機/擴充模組連接座
3	DIN軌固定扣		

■ 外部配線



- 注1: 額比輸出請與其他電源線隔離
- 註 2:如果自戴之輸入端達波太大造成配線受輸銀干禮時,請連接 0.1-0.47μF25V 之電容。 註 3:請將電源模組之Φ結及 DVP04DA-H2 额比信號輸出模組之Φ結連接到系統接地點,再將系統接點作接地或接到
- 注意:空稿子 請勿配線

❷ 規格

數位/類比 (4D/A) 模組	電腦輸出	電流輸出
電源電壓	24V DC (20.4V DC ~ 28.8V DC) (-15% ~ +20%)	
類比訊號輸出運道	4 通道台	
類比輸出範圍	0 - 10V	0 - 20mA
數位資料範圍	0 - 4,000	0 - 4,000
解析度	12 bits (1 _{LSB} = 2.5mV)	12 bits (1 _{LSB} = 5μA)
輸出阻抗	0.5Ω 或更低	
總和精密度	±0.5% 在 (25°C, 77°F) 範圍內護刻度時・±1%	在 (0 ~ 55°C, 32 ~ 131°F) 範圍內滿刻度時・
響應時間	3ms× 通道數	
最大輸出電流	$10mA\left(1K\Omega-2M\Omega\right)$	=
容許負載阻抗	-	0 - 500Ω
數位資料格式	16 位元二補數,有效位 11 bits	
隔離方式	內部電路與類比輸出端以光耦合器隔離,類比逐	動道間末隔離
保護	電腦輸出有短路保護但須注意長時間短路仍有可]能造成內部線路損壞,電流輸出可開路。
通訊模式 (RS-485)		600/19,200/38,400/57,600/115,200 bps),ASCII 模 E. 1)RTU 模式資料格式固定為 8 bits、偶位元、 85 選訊無法使用

數位/類比 (4D/A) 模組	電腦輸出	電流輸出
與 DVP-PLC 主機申接 說明	模組編號以靠近主機之順字自數編號由 0 到 7。	最大可連接 8 台且不佔用數位 I/O 點數 ·

其他規格

	電源規格						
額定最大消耗功率	直流 24V DC (20.4V DC ~ 28.8V DC) (-15% ~ +20%), 4.5W, 由外部電源供應						
環境網格							
操作/储存環境	操作:0°C - 55°C (溫皮) + 50 - 95% (濕皮) + 污染等級 2 : 储存:-25°C - 70°C (溫皮) + 5 - 95% (濕皮) -						
附振動/衝撃	國際標準規範 IEC 61131-2, IEC 68-2-6 (TEST Fc)/IEC 61131-2 & IEC 68-2-27 (TEST Ea)						

❸ 控制暫存器 CR

CR 細號	RS-485 參數位址	保	持型	暫存器名稱	整存器名符 b15 b14 b13 b12 b11 b10 b9 b8 b7 b6 b5 b4 b3 b2 b1							ьо					
#0	H'4032	0	R	機種型號	系統內定,DVP04DA-H2 機窪網碼 = H'6401 使用者可在程式中將此機窪型號讚出,以判斷擴充機組是否存在												
#1	H'4033	0	R/W	輸出模式設定	保留 輸出模式設定 模式 0:電壓 模式 1:電壓 模式 2:電流 模式 3:電流	輸出机 輸出机 輸出机	東式 (0 東式 (2 東式 (4	恒馬 V - W -	H'00 10V) 10V) - 20n	nA)			CH2			СН1	

CR#1 內容值用來設定類比信號輸出模組內部兩個通道的工作模式,每個通道各有四種模式,可獨立設定,例如要將 CHI ~ CH4 分別輸出設定爲 CH1: 模式 2 (b2 ~ b0 = 010) · CH2: 模式 1 (b5 ~ b3 = 001) · 須將 CR#1 設局 H '000A · 較高位的位元 (b12

Lid bie Hill .	TTABLE	DUE 1E	11 0000 ·	
H ⁴⁰³⁸	×	R/W	CH1 輸出數值	
H'4039	X	R/W	CH2 輸出數值	通直CH1 - CH4 輸出數值 · 可設定範匿 K0 - K4,000
H'403A	X	R/W	CH3 輸出數值	出廠設定值爲 KO · 單位爲 LSB ·
H'403B	X	R/W	CH4 輸出數值	
H'4044	0	R/W	CHI 微調 OFFSET 值	滿並 CHI - CH4 訊號的 OFFSET 設定: 可設定範圍 K-2,000 - K2,000 +
H'4045	0	R/W	CH2 微調 OFFSET 值	出廠設定值爲 KO · 單位爲 LSB ·
H'4046	0	R/W	CH3 機調 OFFSET 値	電展列調範置: -2,000 LSB ~ +2,000 LSB
H'4047	0	R/W	CH4 微調 OFFSET 值	電流可調範置: -2,000 ₁₈₈ ~ +2,000 ₁₈₈
H°404A	0	R/W	CHI 微調 GAIN 値	涌並 CH1 - CH4 訊號的 GAIN 設定 : 可設定範圍 K0 - K4,000 : 出癌影
H'404B	0	R/W	CH2 微調 GAIN 值	定值爲 K2,000 · 單位爲 LSB ·
H'404C	0	R/W	CH3 機關 GAIN 値	電壓可調整 範羅 : 0 _{LSB} ~ +4,000 _{LSB} ·
H°404D		R/W	CH4 微調 GAIN 值	電流可調整範圍: 0 _{1.58} ~ +4,000 _{1.58}
	H'4038 H'4039 H'403A H'4044 H'4045 H'4046 H'4047 H'404A H'404A	H'4038 X H'4039 X H'403A X H'403B X H'4044 □ H'4045 □ H'4046 □ H'4047 □ H'404A □ H'404A □ H'404C □	H'4038 X R/W H'4039 X R/W H'4030 X R/W H'4038 X R/W H'4044 O R/W H'4046 O R/W H'4047 O R/W H'4044 O R/W	H 4039 X R/W CH2 輸出數值 H 403A X R/W CH2 輸出數值 H 4044 O R/W CH2 輸出 第

CR#18-CR#27:需特別注意 GAIN 值 - OFFSET 值 = +400 $_{LSB}$ ~ +6,000 $_{LSB}$ (電壓或電流),當此值較小時 (急糾線),對於輸 出信號之解析度較細,數位值變化較大,當出值較大時(緩影線),對於輸出信號之解析度較粗,數位值變化較小。 #30 H'4050 × R 錯誤狀態 儲存所有錯誤狀態的資料暫存器,詳細內容詢參照錯誤信息表

CR#30:錯誤狀態值請參照錯誤狀態表

錯誤狀態	内容值	b15 - b8	Ь7	b6	b5	Ь4	ь3	b2	ь1	ь0
電源異常	K1 (H'1)	保留	0	0	0	0	0	0	0	1
刻度超過	K2 (H'2)	休田	0	0	0	0	0	0	1	0
模式設定錯誤	K4 (H'4)		0	0	0	0	0	1	0	0
OFFSET/GAIN 錯誤	K8 (H'8)		0	0	0	0	1	0	0	0
硬體故障	K16 (H'10)	保留	0	0	0	1	0	0	0	0
變換值異常	K32 (H'20)	休田	0	0	1	0	0	0	0	0
平均次數設定錯誤	K64 (H'40)		0	1	0	0	0	0	0	0
指令錯誤	K128 (H'80)		1	0	0	0	0	0	0	0
22:每個錯誤狀態由相:	對應 之位 元 b0 - b	b7決定,有可	「能會用	转產生雨	個以上	之錯誤狀	態・0 伊	表正常	兵錯誤,	1代表

例:當數位輸 入超過 4000 時會顯示剝度超過 (K2) 錯誤:當賴比輸出超過 10V 時,會同時顯示變換值異常 (K32) 及 制度超過 (K2) 的领域设施

	20 1000 10	(R2	1 0720	166 No. 1872 .									
#31	H'4051	0	R/W	運风位址設定	設定 RS-485 選訊位址 · 設定範圍 01 ~ 254 · 出廠設定值爲 K1 ·								
#32	H'4052	0	R/W	通讯适率設定	設定通訊選率 115,200 bps 六種 (7. E, 1) · RTU 模 出施設定值為 H' b0: 4,800 bps (位 b2: 19,200 bps (位 b4: 57,600 bps (位 b6 - b13: 保留 b14: CRC 檢查碼 b15: ASCII/RTU 表	· ASCII 模式 3 式資料格式 5 0002 · 元/秒); b1: 9 並元/秒); b3: 並元/秒); b5:	資料格式固定: 定馬 8 bits、{ 9,600 bps (位) 38,400 bps (付 115,200 bps (僅 RTU 模式	勝 7 bits、偶位 関位元、1 stop 元/秒)(出版語 立元/秒) 位元/秒)	元、I stop bit bit (8, E, I) 设定值)				
					保留	CH4	CH3	CH2	CHI				
#33	H'4053	0	R/W	恢復出施設定及設定 特性微調權限	出版值 H'0000 1. 當 b0 = 0 時 b0 = 1 時 禁 2. b1 代表是否符 電保持) b1 = 3. b2 設定局 1 民 除外)	可由使用者割 止使用者調整 性微調暫存器 :1 (非停職保)	定 CHI 的特 CHI 特性微調 器爲停電保持 寺)	間 CR#18, CR# ・b1 = 0 (出版	124, 預設值,要停				

CR#33:內容值用來設定一些內部功能的使用權如特性微調暫存器等,而輸出保持的功能將會於斷電前將輸出設定值存於內 部記憶體中

#34	H'4054	0	R	轫體版本	16 進制、顯示目前韌體版本、如 1.0A 則 H'010A
#35 ~	#48				系統內部使用・

○:停電保持型 (須由 RS-485 通訊寫入才有停電保持功能)・

- ×:停電保持型
- R:可使用 FROM 指令讚取資料,或利用 RS-485 通訊讚取資料。 W:可使用 TO 指令寫入資料,或利用 RS-485 通訊寫入資料
- LSB (Least Significant Bit) 最低有效位元值:

電壓輸出:1_{LSB} = 10V/4,000 = 2.5mV · 電流輸出:1_{LSB} = 20mA/4,000 = 5μA

CR#0~CR#34: 對應 之參數位址 H'4032~H'4054 可提供使用者利用 RS-485 通訊來讀 寫資料·由 RS-485 通訊時

須先將模組與主機分離 ·

- 1. 支援傳輸速度 4,800/9,600/19,200/38,400/57,600/115,200 bps
- 2. 可使用 Modbus ASCII 模式/RTU 模式通訊 協定·ASCII 模式資料格式 固定錄 7 bits、偶位元、1 stop bit (7, E, 1) · RTU 模式資料格式固定爲 8 bits · 偶位元 · 1 stop bit (8, E, 1) ·
- 3. 功能碼 (Function): 03'H 讀出暫存器資料・06'H 寫入一個 word 資料至暫存器・10'H 寫入多筆 word 資料
- 4. 停電保持型的 CR 須由 RS-485 通訊來 寫入才有停電保持 的功能:如果是由主機以 TO/DTO 指令寫入則不會 有停電保持的功能。

● 調整 D/A 轉換特性曲線

電壓輸出模式



CR#1 之模式 0	GAIN = 5V (2,000 _{LSB}). OFFSET = 0V (0 _{LSB}).
CR#1 之模式 1	GAIN = 6V $(2,400_{LSB})$. OFFSET = 2V (800_{LSB}) .
GAIN	當數位輸入值爲 $K2,000$ 時的電壓輸出值 · 設定範圍: $0_{LSB} \sim +4,000_{LSB}$ ·
OFFSET	當數位輸入值寫 K0 時的電 團輸出值·設定範圍: -2,000 _{LSB} - +2,000 _{LSB} ·
GAIN - OFFSET	範圍須在 +400 _{LSB} ~ +6,000 _{LSB} 之間・

電流輸出模式




CR#1 之模式 2	GAIN = $12\text{mA}\ (2,400_{LSB})$. OFFSET = $4\text{mA}\ (800_{LSB})$.
CR#1 之模式 3	$GAIN = 10mA~(2,000_{LSB}).~OFFSET = 0mA~(0_{LSB}). \label{eq:GAIN}$
GAIN	當數位輸入值爲 K2,000 時的電流輸出值·設定範圍: O _{LSB} ~ +4,000 _{LSB}
OFFSET	當數位輸入值爲 K0 時的電流輸出值·設定範圍: -2,000 _{LSB} - +2,000 _{LSB} ·
GAIN - OFFSET	節節須在 +400 +6,000 之間・

注意事项

- ✓ 请在使用之前,详细阅读本使用说明书。
- 实施配线,务必关闭电源。
- ✔ 本机为开放型 (OPENTYPE) 机壳,因此使用者使用本机时,必须将其安装于具防尘、防網及免于电击 / 冲 击意外的外壳配线箱内。另必须具备保护措施(如: 特殊的工具或钥匙才可打开)防止非维护人员操作或意
- ✓ 输入电源不可连接于输入/出信号端,否则可能造成严重损坏,请在上电之前再次确认电源配线。
- ✔ 请勿在上电时触摸任何端子。输入电源切断后,一分钟之内,请勿触摸内部电路。
- ✓ 本体上的接地端子 ④ 务必正确的接地·可提高产品抗噪声能力。


❶ 产品简介

- 型号说明及周边装置
- 感谢您采用台达 DVP 系列产品,DVP04DA-H2 模拟信号输出模块可透过 DVP-EH2 系列主机程序以指令 FROM/TO来读写 DVP04DA-H2模拟信号输出模块的数据。而模拟信号输出模块接受来自 PLC 主机的 4 组 12 位 数字数据,再将数字数据转换为 4 点模拟信号输出(电压或电流皆可)。
- 使用者可经由配线选择电压输出或电流输出,电压输出范围 0V~+10V DC (分辨率为 2.5mV),电流输出 范围 0mA~20mA (分辨率为 5μA).
- 产品外观及各部介绍



0	DIN 纨糟 (35mm)	6	端子
2	扩展机 / 扩展模块连接口	Ø	固定孔
3	机种名称	8	端子配置
9	电源、错误及转换指示灯	9	扩展机 / 扩展模块连接座
(S)	DIN執固定和		

■ 外部配线



- 注 1: 模粒绘出设与其实会源线隔离
- 近1. 按照相目识可决定公公共间隔。 注2: 如果真軟的稱入構造及大連成配為受噪声干扰時,请提接0.1-0.47µF25V 的电容。 注3: 请将电源模块的 ❷ 端及 DVP04DA-H2 模拟信号输出模块的 ❸ 端挂接到系统接地点,再将系统接点作接地或 接到配电箱的机壳上。

❷ 规格

注意:空稿子 ● 请勿配线。

数字 / 模拟 (4D/A) 模块	电压输出	电流输出						
电源电压	24V DC (20.4V DC - 28.8V DC) (-15% - +2	20%)						
模拟信号输出通道	4 通道/台							
模拟输出范围	0 - 10V	0 ~ 20mA						
數字數据范围	0 - 4,000	0 ~ 4,000						
分辨率	12 bits (1 _{LSB} = 2.5mV)	12 bits (1 _{LSB} = 5μA)						
输出阻抗	0.5Ω 或更低	5Ω 或更低						
总和精密度	±0.5% 在(25°C, 77°F)范围內满刻度时。							
85年前100R	±1% 在 (0 - 55°C, 32 - 131°F) 范围內满刻度时.							
响应时间	3ms×通道数							
最大输出电流	10mA (1KΩ ~ 2MΩ)	-						
容许负载阻抗		$0 \sim 500\Omega$						
数字数据格式	16 位 二补码, 有效位 11 bits							
隔离方式	內部电路与模拟输出端以光耦合器隔离,	模拟通道 间未隔离。						
保护	电压输出有短路保护但须注意长时间短路	仍有可能造成内部线路损坏,电流输出可开路。						
道讯模式 (RS-485)	但含 ASCII/RTU 模式,通讯渔率可速(4,800%,600/19,200/38,400/57,600/15,200 bps), ASCII 模式数据格式固定为7-bit、偶位、1 stop bit (7,E, 1), RTU 模式数据格式固定为8-bit、偶位、1 stop bit (8,E, 1). 当与 PLC 主机申接时, RS-485 通讯无法使用。							
与 DVP-PLC 主机申接说明	模块编号以靠近主机的顺序自动编号由 0	到7,最大可连接8台且不占用数字I/O点数。						

其它规格

模式设定错误

K4 (H°4)

簡体中文

	电源规格
额定最大消耗功率	直流 24V DC (20.4V DC ~ 28.8V DC) (-15% ~ +20%), 4.5W, 由外部电源供应.
	环境规格
操作 / 储存环境	操作: 0°C - 55°C (温度), 50 - 95% (湿度), 污染等级 2 缩存: -25°C - 70°C (温度), 5 - 95% (湿度)
耐振动 / 冲击	国际标准规范 IEC 61131-2, IEC 68-2-6 (TEST Fe)/IEC 61131-2 & IEC 68-2-27 (TEST Ea)

❸ 控制寄存器 CR

CR 编号	RS-485 参数地址	伢	特型	寄存器名称	b15 b14 b13 b12 b11 b10 b9 b8 b7 b6 b5 b4 b3 b2 b1							ьо				
#0	H'4032	0	R	机种型号	系统内定, DVP04DA-H2 机种编码 = H'6401 使用者可在程序中将此机种型号读出,以判断扩展模块是否存在。											
#1	H°4033	0	R/W	输出模式设定	保留 输出模式设定: 1 模式 0. 电压输出 模式 1. 电压输出 模式 2. 电流输出 模式 3. 电流输出	模式 (0° 模式 (2° 模式 (4r	直为 V ~ 1 V ~ 1 nA ~	H'00 0V) 0V) 20m	A)			CH2			СН1	

					18.14.2: 4202.00 Life.14. (400.4 ~ 2000.4)						
					模式 3: 电流输出模式 (0mA ~ 20mA)						
CR#1	内容值用:	来设	定模拟	信号输出模块内部两个注	直道的工作模式,每个通道各有四种模式,可独立设定、例如要将 CH1						
CH4 5	·别输出设	定为	CHI:	模式 2 (b2 ~ b0 = 010),	CH2:模式 1 (b5 - b3 = 001),须将 CR#1 设为 H'000A,较高位的位 (b)						
~ b15)	将保留.	出厂	设定值	为 H'0000.							
#6	H°4038	X	R/W	CH1 输出数值							
#7	H°4039	X	R/W	CH2 输出数值	通道 CH1 - CH4 输出数值,可设定范围 K0 - K4,000.						
#8	H°403A	×	R/W	CH3 输出数值	出厂默认值为 KO, 单位为 LSB.						
#9	H'403B	X	R/W	CH4 输出数值							
#18	H'4044		R/W	CHI 微调 OFFSET 值	通道 CH1 - CH4 信号的 OFFSET 设定,可设定范围 K-2.000 - K2.000						
#19	H°4045		R/W	CH2 微调 OFFSET 值	出厂默认值为 KO, 单位为 LSB.						
#20	H°4046		R/W	CH3 微调 OFFSET 值	电压可调范图: -2,000 LSB ~ +2,000 LSB.						
#21	H°4047		R/W	CH4 微调 OFFSET 值	电流可调范围: -2,000 _{LSB} - +2,000 _{LSB} .						
#24	H'404A		R/W	CH1 微调 GAIN 值	通道 CH1 - CH4 信号的 GAIN 设定,可设定范围 K0 - K4.000.						
#25	H'404B		R/W	CH2 微调 GAIN 值	出厂款认值为 K2,000, 单位为 LSB.						
#26	H'404C		R/W	CH3 衡调 GAIN 值	电压可调整范围: 0 _{LSB} - +4,000 _{LSB} .						
#27	H'404D		R/W	CH4 微调 GAIN 值	电流可调整范围: 0 _{1.58} ~ +4,000 _{1.58} .						
					.000 _{LSB} (电压或电流),当此值较小时(急斜线),对于输出信号的分辨						
较细,	数子值变	化較	大, 自	9此值収天町(缵斜线)。 ·	对于输出信号的分辨率较粗,数字值变化较小.						
#30	H'4050	X	R	错误状态	储存所有错误状态的数据寄存器,详细内容请参照错误信息表。						

CR#30: 错误状态值请参照错误状态表 错误状态 内容值 b15~b8 b7 b6 b5 b4 b3 b2 b1 b0 电缆异常 K1 (H^{*}1)
 0
 0
 0
 0
 0
 0
 1

 0
 0
 0
 0
 0
 1
 0

 0
 0
 0
 0
 1
 0
 0
 保留 刻度超过 K2 (H'2)

编号	参数地址	保持型	寄存器	名称	ь15	ь14	ь13	ь12	ь11	ь10	ь9	ь8	ь7	ь6	b5	Ь4	ь3	ь2	ы	ь0
	错误状法	ės –	内容值	b15 - b8		ь7	ŧ	06	1	55	ь	4	ь3		ь2		ы	ī	ь0	
OF	FSET/GAL	N错误	K8 (H'8)			0		0		0	C		1	П	0	П	0	Т	0	
硬	件故障		K16 (H'10)			0		0		0	1		0	П	0	Т	0	Т	0	
变	变换值异常		K32 (H'20)	保留		0		0		1	0	,	0	П	0	Т	0	Т	0	
平均次数设定错误		错误	K64 (H'40)	米田		0		1		0	C	1	0		0		0		0	

CD DC 405

- 注: 每个错误状态由相对应的位 60-67决定, 可能会同时产生两个以上的错误状态, 0 代表正常无错误, 1 代表有错
- 例:当数字输入超过 4000 时会显示刻度超过 (K2) 错误:当模拟输出超过 10V 时,会同时显示变换值异常 (K32) 及 刻度超过 (K2) 的错误状态

#31	H'4051		R/W	通讯地址 设定	设定 RS-485 通讯	地址,设定范	图 01 ~ 254.	出厂默认值为	K1.		
#32	H'4052	0	R/W	通讯递率 设定	花經經過率, 并有4800,90019-200 bps/32,000 bps/72,001 15,200 bps/产体 ASCH 氨式液混构式温度为7 biss. (角性), 1 E. J., KTU 最次激解式温度分 biss. (角性) 1 sep bis (条 E. 景试路 b H 10002. bb 4800 bps (②/b²), bi: 9,600 bps (②/b²) (当广款认值) bi: 19200 bps (②/b²), bi: 13,8000 bps (②/b²) bi: 17,600 bps (②/b²), bi: 11,200 bps (②/b²) bi- bii: (张伊) bi- bii: (张伊) bist- SCKUPCTU 每次就除。 0 ASCH 每次 (○ FE认论)						
					保留	CH4	CH3	CH2	CHI		
#33	H'4053	0	R/W	恢复默认 设定及 设定 特性衡调 权限	出厂值 H'0000, 1. 当 b0 = 0 时, b0 = 1 时,禁1 2. b1 代表是否特 停电保持), b1 3. b2 设定为 1 时	可由使用者设 上使用者调整 性微调寄存器 =1(非停电	定 CH1 的特性 CH1 特性復识 为停 电保持, 保持).	CR#18, CR#2 b1 = 0 (Ш/	24. 默认值,要		

CR#33: 内容值用来设定一些内部功能的使用权如特性微调寄存器等。而输出保持的功能将会于断电前将输出设定值存于

34	H°4054		R	韧体版本	16进制,显示目前韧体版本,如 1.0A 则 H'010A.				
26	#49				彩練 由維維用				

符号定义:

- ○: 停电保持型(須由 RS-485 通讯写入才有停电保持功能)
- ×:非停 电保持型 R:可使用 FROM 指令读取数据,或利用 RS-485 通讯读取数据.
- W:可使用 TO 指令写入数据,或利用 RS-485 通讯写入数据。 LSB (Least Significant Bit) 最低有效价值:
- 电压输出: $1_{LSB} = 10V/4,000 = 2.5 \text{mV}$. 电流输出: $1_{LSB} = 20 \text{mA}/4,000 = 5 \mu \text{A}$.

CR#0~CR#34:对应的参数地址 H'4032~H'4054 可提供使用者利用 RS-485 通讯来读写数据,由 RS-485 通讯时 须先将模块与主机分离.

- 1 支持传输速度 4 800/9 600/19 200/38 400/57 600/115 200bps
- 2. 可使用 Modbus ASCII 模式/RTU 模式通讯协议,ASCII 模式数据格式固定为 7-bit、偶位、1 stop bit (7, E, 1),
- RTU 模式数据格式固 定为 8-bit、偶位、1 stop bit (8, E, 1) . 3. 功能网 (Function): H'03 读出 寄存器数据,H'06 写入一个 word 数据至寄存器,H'10 写入 多笔 word 数据
- 至 客存器。
- 4. 停电保持型的 CR 须由 RS-485 通讯来写入才有停电保持的功能, 如果是由主机以 TO/DTO 指令写入则不会 有停电保持的功能。

母 调整 D/A 转换特性曲线

电压输出模式



	以 于他八
CR#1 的模式 0	GAIN = 5V (2.000_{LSB}) . OFFSET = 0V (0_{LSB}) .
CR#1 的模式 1	GAIN = 6V (2,400 _{LSB}). OFFSET = 2V (800 _{LSB}).
GAIN	当数字输入值为 K2,000 时的电压输出值,设定范围: 0 _{1.58} ~ +4,000 _{1.58} .
OFFSET	当数字输入值为 K0 时的电压输出值,设定范围: -2,000 _{LSB} ~ +2,000 _{LSB} .
GAIN - OFFSET	范围须在 +400 _{LSB} - +6,000 _{LSB} 之间.

电流输出模式



	CR#1 的模式 2	GAIN = $12mA$ (2,400 _{LSB}). OFFSET = $4mA$ (800 _{LSB}).
	CR#1 的模式 3	GAIN = $10\text{mA} (2,000_{LSB})$. OFFSET = $0\text{mA} (0_{LSB})$.
	GAIN	当数字输入值为 K2,000 时 的电流输出值, 设定范围: 0 ₁₅₈ ~ +4,000 ₁₅₈ .
	OFFSET	当数字输入值为 K0 时的电流输出值,设定范围: -2,000 _{Lsm} ~ +2,000 _{Lsm} .
	GAIN - OFFSET	范围须在 +400, sn - +6,000, sn 之间.